

VEHICLE BRAND

[Audi](#)[Bentley](#)[BMW](#)[Can-Am](#)[Case IH](#)[Citroen](#)[Claas](#)[Cupra](#)[Dacia](#)[Deutz](#)[Fiat](#)[Ford](#)[FPT Industrial](#)[Hyundai](#)[Iveco](#)[Indian Mot.](#)[Jaguar](#)[Kia](#)[Kramer](#)[Link & Co.](#)[Lamborghini](#)[Landini](#)

[Land Rover](#)

[Man Truck](#)

[Mc Cormik](#)

[Mercedes Benz](#)

[Mini](#)

[New Holland](#)

[Nissan](#)

[Opel](#)

[Peugeot](#)

[Porsche](#)

[Renault](#)

[Rolls Royce](#)

[Seat](#)

[Skoda](#)

[Steyr](#)

[Toyota](#)

[Suzuki](#)

[Volkswagen](#)

[Volvo](#)

| Vehicle Brand | ECU Brand | Model ECU | Micro | Flash | ECU Clonable (YES) |
|-------------------|-----------|-----------|---------------------------|---------|--------------------|
| Agco | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Alfa Romeo | Bosch | EDC16C8 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Audi | Bosch | EDC16C4 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5.10 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| BMW | Bosch | EDC16C1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C35 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP35 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Cadillac | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Case | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Chevrolet | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Chrysler | Bosch | EDC16C2 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Citroen | Bosch | EDC16C34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Daewoo | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Deutz | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16UC40 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Dodge | Bosch | EDC16CP31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Fiat | Bosch | EDC16C8 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Fendt | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |

| | | | | | |
|------------------------|-------|-----------|---------------------------|---------|-----------------|
| Ferrari | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Ford | Bosch | EDC16C34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | ME9.0 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Freightliner | Bosch | EDC16CP31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| GMC | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Holden | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Honda | Bosch | EDC16C7 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Hyundai | Bosch | EDC16CP39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Iveco | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C8 | MPC556 | | |
| | Bosch | EDC16C39 | MPC556 | | |
| Jeep | Bosch | EDC16CP31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Kia | Bosch | EDC16CP39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| KTM | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Lamborghini | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16UC40 | MPC554 | | |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1.2 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Lancia | Bosch | EDC16C8 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Landini | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Linde AG | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| MAN | Bosch | EDC7C32 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Massey Ferguson | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Mazda | Bosch | EDC16C34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Mercedes Benz | Bosch | EDC16C2 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C32 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP36 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| New Holland | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Nissan | Bosch | EDC16C41 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP33 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Opel | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |

| | | | | | |
|----------------|-------|-----------|---------------------------|---------|-----------------|
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | ME9.X | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | PSG16 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Peugeot | Bosch | EDC16C34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Porsche | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Renault | Bosch | EDC16C36 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C41 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP33 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Saab | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | ME9.X | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | PSG16 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Same | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Saturn | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | ME9.X | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Seat | Bosch | EDC16U1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5.10 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Skoda | Bosch | EDC16U1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5.10 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Smart | Bosch | EDC16C32 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Subaru | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Suzuki | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |

| | | | | | |
|-------------------|-------|-----------|---------------------------|---------|-----------------|
| Toyota | Bosch | EDC16C10 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Valtra | Bosch | EDC7UC31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Vauxhall | Bosch | EDC16C9 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16C39 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | ME9.X | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.6.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | PSG16 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Volkswagen | Bosch | EDC16C4 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16CP34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | EDC16U34 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.1.1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | MED9.5.10 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Volvo | Bosch | EDC16C31 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| | Bosch | ME9.0 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |
| Yamaha | Bosch | EDC16C1 | Motorola Freescale MPC5xx | Int-Ext | CONTACT SUPPORT |